


## Power Supply Preparations

The illustration of the grip band is omitted.


### Using dry-cell batteries (not supplied)



#### Caution:

Do not forcibly open the battery lid too wide.

### Battery indicator




This indicator appears when the batteries are almost out of power. Power will be cut off a short while later.

#### Note:

Turning off the Anti-Shock Protection EX will save the battery power more or less. For details, see "Anti-shock Protection EX" on page 4. (Available for an Audio CD only)

### Using the AC adaptor (not supplied)




#### Notes:

- Even if the unit is turned off, small power is consumed as long as the AC adaptor is connected to the AC power outlet.
- When you want to purchase the AC adaptor, see page 5.

### AC adaptor (for multi voltage area only) (not supplied)


#### Before use

Make sure the present voltage of your AC adaptor fits to your local voltage before plugging it into the AC power outlet. If it doesn't, shift the AC line-voltage selector with a screwdriver so that it corresponds to your local voltage.



If the power plug will not fit your socket, use the AC plug adaptor.

### How to use the AC plug adaptor (not supplied)




#### Note:

When you want to purchase the AC adaptor and the AC plug adaptor, see page 5.

## Basic Play

The illustration of the grip band is omitted.



Operation	Button	Display/reference	
		Audio CD	MP3
To pause	Press again to restart play.	0700:18-	01 0400:07-
To stop		Total number of tracks 10 44:48 Total playing time	Total number of groups 10 35 Total number of tracks
To turn off the unit		No indication	
Fast forward/reverse	Reverse Forward	<ul style="list-style-type: none"> <li>• To skip back to the previous track, quickly press  twice.</li> <li>• During Program play, the button is used to fast forward or back through the programmed sequence of tracks.</li> <li>• During Random play, the skip button cannot be used to skip back to tracks that were played previously in the random sequence.</li> </ul>	
Group skip (MP3 only)		Group number 02 01	

#### For your reference:

##### "disc"

This indication appears if is pressed when no disc is loaded or if the disc is not properly seated.

##### "\_ \_"


Preparation period before playing the track. Flashes for several seconds after pressing to play.

##### "OPEN"

This indication appears when the lid is open.

##### Removing discs

Turn off the unit and, after the disc has stopped rotating, remove the disc as shown below:



##### Auto power off

If the unit is left in stop mode for 30 seconds, the unit turns itself off automatically to prevent the batteries from running down.

##### Disc rotation noise


The portable CD player uses a power-saving operation method so that disc rotation noise will intermittently be emitted. But, it is not a failure.

## Other Play Methods

### Intro play

You can successively play the first 10 seconds of every track.

#### 1 While stopped,



#### 2



#### To cancel


Press MODE repeatedly until "INTRO" goes out.

#### Notes:

- You can also select Intro play during playback. In this case, Intro play will start from the next track after the current track has finished.
- You can also select Intro play during Program play mode.

### Random play

#### During playback,



After playing all tracks, the unit stops.

#### To cancel

Press MODE until "RND" goes out, or press to stop the disc.

#### Notes:

- You can also select Random play in stop mode.
- During Program play, you can not select Random play.


### Program play

You can program up to 64 tracks in any desired order including the same tracks.


For Audio CD, go to step 3.

Though the display differs a little, operation is the same.

#### 1 While stopped, (MP3 only)




#### 2 (MP3 only) Select the desired group number. (e.g.02)



#### 3



#### 4 Select the desired track.



#### 5



The track is registered.

#### 6 For MP3, repeat steps 2-5 to select other tracks. For Audio CD, repeat steps 4 and 5.

When you program exceeding 64 tracks, the program sequence number returns to "01" and will overwrite the previous setting.

#### 7



#### To confirm the program

While stopped, press PROGRAM repeatedly. At this time, you can add and change the program, if required.


#### To delete the entire program

While stopped, press STOP. Or turn off the unit.

### Repeat play

You can repeat one track or all tracks.

#### During playback,



#### To cancel


Press MODE repeatedly until the repeat indicator goes out.

#### Notes:

- You can also select Repeat play during Program play.
- You can also select Repeat play while stopped.

### Hyper-Bass Sound effect

You can enjoy powerful bass sound.



### Anti-Shock Protection EX

This function achieves excellent performance against sound interruption caused by vibrations. You will be able to enjoy listening to music during (not vigorous) jogging.

By utilizing the high-performance servo circuit, audio data will be stored in the memory ahead of time.

For Audio CD: Up to 40 seconds worth (Anti-Shock Protection on/off selectable)

For MP3: Up to 100 seconds worth at 128 kbps (Anti-Shock Protection is fixed to on.)

Normally, this function is in effect.



As the audio data is gradually stored, the indicator changes as follows:



#### To cancel (Audio CD only)



The "ANTI SHOCK" indicator goes out.

#### To activate again (Audio CD only)

Press A.S.P/GROUP UP.

#### Notes:

- During this operation, the disc rotates at a higher rate than usual in order to collect extra audio data. This may cause the batteries to run out faster and could result in a slight increase in disc rotation noise.
- This function can be switched ON and OFF during playback. However, this may cause a slight interruption in the sound because the disc's rotational speed changes.

## Cautions

### Listening precautions



Do not play your headphones or earphones at a high volume. Hearing experts advise against continuous extended play.

If you experience a ringing in your ears, reduce volume or discontinue use.

Do not use while operating a motorized vehicle. It may create a traffic hazard and is illegal in many areas.

You should use extreme caution or temporarily discontinue use in potentially hazardous situations.

Even if your headphones or earphones are an open-air type designed to let you hear outside sounds, don't turn up the volume so high that you can't hear what's around you.

Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So what sounds "normal" can actually be loud and harmful to your hearing.

Guard against this by setting your equipment at a safe level BEFORE your hearing aids.

To establish a safe level:

- Start your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, and without distortion.

Once you have established a comfortable sound level:

- Set the dial and leave it there.

### Rechargeable batteries

- Rechargeable batteries (not supplied) can be used.
- To use the rechargeable batteries, follow the instruction manual attached to the rechargeable batteries and charger (not supplied).

### Dry cell batteries

To prevent damage to the batteries and electrolyte leakage, heed the following points.

- Align the ⊕ and ⊖ polarities properly when inserting the batteries.
- Do not mix different types or makers of batteries or old and new batteries.
- Remove the batteries if you do not plan to use the unit for a long period of time.
- Do not throw batteries into a fire, and do not short-circuit, disassemble or subject them to excessive heat.
- Do not attempt to recharge dry cell batteries.

### Carrying dry cell batteries around

When putting dry cell batteries in a pocket or bag, ensure that no other metal objects such as a necklace are placed together with them. Contact with metal may cause short-circuiting which, in turn, may cause a fire.

### AC adaptor

- Handle the AC adaptor carefully. Improper handling is dangerous.

- Do not touch it with wet hands.
- Do not place heavy objects on top of it.
- Do not forcibly bend it.

- Be sure to connect only the specified AC adaptor with the unit.
- Disconnect the AC adaptor from the power outlet if the unit is not going to be used for a long time.

### Unit

#### No altering or remodeling

This can cause malfunctioning.

#### No dropping or strong impacts

This may damage the unit.

#### Locations to be avoided

Avoid using the unit in the following locations since they can cause malfunctioning.

1. Bathrooms and other moisture-prone places.
2. Warehouses and other dusty places
3. Very hot places near heating appliances, etc.

#### Do not leave the unit exposed to direct sunlight for long periods of time

This may deform or discolor the cabinet and may also cause malfunctioning.

### When purchasing AC adaptor / AC plug adaptor

Be absolutely sure to purchase the AC adaptor / AC plug adaptor designed especially for this unit.

#### AC adaptor: AA-R4513 (for the U.S.A. and Canada)

#### AA-R4518 (for multi voltage area)

#### AC plug adaptor: QAM0060-001 (for multi voltage area)

For details, check with your dealer.

## Precautions

### Safety

1. **Care of AC adaptor** - The cord of the AC adaptor should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Never take hold of the AC adaptor if your hand is wet, and always grasp the plug when connecting or disconnecting it.

2. **Disconnect when not in use** - When not in use, be sure to disconnect the AC adaptor from the AC power outlet.

3. **Batteries** - If the unit is not used for a long period of time or is used only from an AC power source, remove all the batteries to prevent potential damage due to battery leakage. Do not mix (old and new ) batteries or different types of batteries.

### Installation

#### ■ Environment

1. **Condensation** - Moisture may form on the lens in the following conditions...
  - immediately after a heater has been turned on.
  - in a steamy or very humid room.
  - when the unit is suddenly moved from a cold environment to a warm one. If moisture forms inside this unit, it may not operate properly. To correct this problem wait about one hour for the moisture to evaporate.

#### ■ Placement

1. **Foreign Material** - Care should be taken so that objects do not fall into and liquids are not spilled into the unit. Do not subject this unit to excessive smoke, dust, mechanical vibration, or shock.
2. **Magnetism** - The unit should be situated away from equipment or devices that generate strong magnetic fields.
3. **Stacking** - Do not place any objects on top of the unit.

### Maintenance

(See page 5 for details.)

Clean the cabinet, panel and controls with a soft cloth lightly moistened with mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzine.

### Service

1. **Damage Requiring Service** - The unit should be serviced by qualified service personnel when:
  - (a) The AC adaptor is damaged; or
  - (b) Objects have fallen or liquid has been spilled into the unit; or
  - (c) The unit has been exposed to rain; or
  - (d) The unit does not appear to operate normally or exhibits a marked change in performance; or
  - (e) The unit has been dropped, or the enclosure damaged.

### WARNING:

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

### CAUTION!

THIS PRODUCT UTILIZES A LASER. USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE. DO NOT OPEN COVERS AND DO NOT REPAIR YOURSELF. REFER SERVICING TO QUALIFIED PERSONNEL.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

#### INFORMATION (For Canada)

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus", ICES-003 of the Department of Communications.

#### CAUTION:

- Do not block the ventilation opening or holes. (If the ventilation openings of holes are blocked by a newspaper or cloth, etc., the heat may not be able to get out.)
- Do not place any naked flame sources, such as lighted candles, on the apparatus.
- When discarding batteries, environmental problems must be considered and local rules or laws governing the disposal of these batteries must be followed strictly.
- Do not expose this apparatus to rain, moisture, dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

#### IMPORTANT FOR LASER PRODUCTS

1. CLASS 1 LASER PRODUCT
2. **CAUTION:** Do not open the top cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
3. **CAUTION:** Visible and invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
4. REPRODUCTION OF LABEL: CAUTION LABEL, PLACED OUTSIDE THE UNIT.

**CAUTION:** Visible and invisible laser radiation when open and interlock failed or defeated. AVOID DIRECT EXPOSURE TO BEAM. (e)

**WARNING:** Synlig Och osynlig laserstrålning när den öppnas och spärren är urkopplad. Betrakta ej strålen. (s)

**ADVARSEL:** Synlig og usynlig laserstråling når maskinen er åben eller interlocken fejler. Undgå direkte eksponering til stråling. (d)

**VARO:** Avattaessa ja Suojalukitus ohitettunatai viiallisena olet alttiina näkyvälle ja näkymättömälle lasersäteilylle. Vältä säteelen kohdistumista suoraan itseesi. (f)

THE FOLLOWING NOTICES ARE APPLIED ONLY FOR THE U.S.A.:

### CAUTION!

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any unauthorized changes or modifications to this equipment would void the user's authority to operate this device.


## Concerning Compact Discs

Only compact discs bearing this mark can be used with this unit.




However, continued use of irregular shape CDs (heart-shape, octagonal, etc.) can damage the unit.

CD-R and CD-RW discs recorded with the audio CD format can be played back, though some may not be played back because of the disc characteristics or recording condition.



The Non-DVD side of a "DualDisc" does not comply with the "Compact Disc Digital Audio" standard. Therefore, the use of Non-DVD side of a DualDisc on this product may not be recommended.


#### How to hold a disc



#### If the disk surface is dirty

Wipe it with a damp cloth and then wipe dry.

Wipe from the center toward the outer edge.



#### If moisture has formed on a disc

When moisture has formed because the disc was brought suddenly into a warm room from a cold environment, wipe off the moisture using a soft dry cloth.

#### When storing discs

Avoid locations which are

- Exposed to direct sunlight.
- Susceptible to high levels of humidity or dust.
- Directly exposed to heat from a heating appliance.
- On top of a car dashboard or near the rear window.

#### Handling precautions

- Do not write anything using a pencil, ball-point pen, etc. Do not use adhesive paper or labels.
- On the disc (shiny) side Handle this side carefully to keep it free from fingerprints or scratches. Do not use record cleaners, solvents, etc.
- Do not attach labels or stickers to CDs. Do not use CDs with exposed adhesive from tape or left over peeled off stickers.
- Do not use scratch-proof protectors or covers other than those specified for use with this unit.

## Specifications

#### Portable CD player

Type	: Compact disc player
Signal detection system	: Non-contact optical pickup (semiconductor laser)
Pickup system	: 3 beam laser
Number of channels:	: 2 channels (stereo)
Frequency response	: 20 Hz to 20 kHz
Wow & flutter	: Unmeasurable
Output	: Headphones (3.5 mm dia. stereo x1) 9 mW/ch at 10 % THD / 16 Ω matching impedance (16 Ω to 1 kΩ) : Approx. 20 hours when using two alkaline batteries (LR6)

Duration of battery (with Anti-Shock Protection EX OFF)	: DC 3 V ("AA" or "LR6" size battery x 2) DC 2.4V (rechargeable battery x 2) DC IN 4.5 V
Dimensions (W×H×D)	: 138mm x 26 mm x 138 mm (5 <sup>-7/16</sup> " x 1 <sup>-1/16</sup> " x 5 <sup>-7/16</sup> " ) (Excluding buttons and controls)
Mass	: 240 g (0.53 lbs) (with grip band, without batteries)

#### AC adaptor (not supplied)

Input power source	: AC 120 V, 60 Hz
Output voltage	: DC 4.5 V, 600 mA

\* Design and specifications are subject to change without notice.

# JVC


## PORTABLE CD PLAYER XL-PM5H

#### For Customer Use:

Enter below the Model No. and Serial No. which are located on back of the lid. Retain this information for future reference.

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_



## INSTRUCTIONS



### Supplied Accessories

Stereo headphones ..... 1 pc.

Thank you for purchasing this JVC product. Please read these instructions carefully before starting operation to be sure to obtain optimum performance and a longer service life from the unit.



0105SKMCREORI

EN ©2005 Victor Company of Japan, Limited

LVT1296-001A [J,C,UJ]

## Troubleshooting

Problem	Check this
Does not turn on.	<ul style="list-style-type: none"><li>• Is the AC adaptor securely connected?</li><li>• Is the HOLD switch set to OFF position?</li></ul>
Cannot close the lid.	Is the disc properly secured in place?
Cannot play discs.	<ul style="list-style-type: none"><li>• Is the disc properly secured in place?</li><li>• Is there moisture condensation on the lens? (Wait for about an hour and then try again.)</li><li>• Are MP3 files recorded on the disc?</li><li>• Do MP3 files have the extension code—mp3?</li><li>• Are MP3 files recorded in the format compliant with ISO 9660?</li></ul>
Cannot hear music—too noisy.	<ul style="list-style-type: none"><li>• Is the headphone plug inserted all the way?</li><li>• Is the plug dirty? (Wipe away dirt on the plug.)</li><li>• Are you playing a compatible disc? While playing a non-MP3 file, you will hear a noise. (Note it may not be an MP3 file although it has the extension code—mp3.)</li></ul>
TV picture is distorted. Radio reception is noisy.	Are you using the unit too near a TV or tuner? (If the TV or tuner is connected to a simple indoor antenna, connect it to an outdoor antenna.)
"dISC" or "Er" is displayed when a disc is in the player.	<ul style="list-style-type: none"><li>• Is the disc damaged?</li><li>• Is the disc playable on this player?</li><li>• Has the disc been inserted upside down?</li></ul>

If the remedies indicated in the chart do not solve the problem, refer to the directory of Authorized Service Centers (enclosed with this unit) to locate a convenient service center, or consult your dealer for instructions.

## Maintenance

#### Unit

Wipe the unit with a soft cloth. Remove stubborn dirt using a cloth which has been dipped in water or soapy water and wrung out, and then wipe dry.

- If you intend to use a chemically treated cleaning cloth, read its directions first.
- Do not use alcohol or paint thinners.

#### Lens

