

Scanner User's Guide

Version 1.3

1200dpi Color Flatbed Scanner



- Installation
- Usage & Maintenance
- Troubleshooting



All trademarks and brand names mentioned in this publication are property of their respective owners.

© 2001. All rights are reserved. No portion of this document may be reproduced without permission.

Table of Contents

INTRODUCTION	1
HOW TO USE THIS GUIDE	1
CONVENTIONS OF THIS GUIDE	2
A NOTE ABOUT ICONS	2
SYSTEM REQUIREMENTS	3
BOX CONTENTS	3
PRODUCT INFORMATION.....	4
CHAPTER I. INSTALLING THE PLUSTEK OPTICPRO SCANNER	5
SOFTWARE INSTALLATION REQUIREMENTS	5
HARDWARE REQUIREMENTS	5
INSTALLING AND SETTING UP THE SCANNER.....	6
<i>Step 1. Unlock Your Scanner First.....</i>	<i>6</i>
<i>Step 2. Connecting the OpticPro Scanner to Your Computer.....</i>	<i>7</i>
<i>Step 3. Installing the Software</i>	<i>8</i>
SOFTWARE SETUP TROUBLESHOOTING.....	10
INSTALLING ADDITIONAL SOFTWARE	10
INSTALLING THE TRANSPARENCY ADAPTER*	10
CHAPTER II. USAGE AND MAINTENANCE	12
OPERATING THE SCANNER.....	12
<i>Testing the Scanner.....</i>	<i>13</i>
THE SCANNER UTILITY PROGRAM.....	14
<i>Connection Status</i>	<i>15</i>
<i>Aligning the Scanner.....</i>	<i>15</i>
LAMP CONTROL.....	16
MAINTENANCE	16
REMOVING THE DOCUMENT COVER	17
USING THE TRANSPARENCY ADAPTER*	17
<i>The Frame Holders.....</i>	<i>17</i>
<i>Important Notes about Scanning Film.....</i>	<i>19</i>
APPENDIX A: TROUBLESHOOTING	20
SCANNING PROBLEMS	20
COMMON -HOW-TO- QUESTIONS	23
APPENDIX B: SPECIFICATIONS.....	25
APPENDIX C: CUSTOMER SERVICE AND WARRANTY	27
STATEMENT OF LIMITED WARRANTY	27
FCC RADIO FREQUENCY STATEMENT	29
CONTACTING PLUSTEK	30

Introduction

Welcome to the world of Plustek scanners – the ultimate in computer imaging. Your new scanner will improve the professionalism of your day-to-day computing tasks by allowing you to input images and electronic text into your computer system.

Like all of our products, your new scanner is thoroughly tested and backed by our reputation for unsurpassed dependability and customer satisfaction.

Please remember to register your scanner. Registration may be completed in one of three ways:

- 1) By registering online via Plustek's Web Site;
- 2) By printing out and faxing a completed registration card to Plustek's customer service center;
- 3) By printing out and mailing the registration card directly to the Plustek office nearest you.

See the last page of this user's guide for a complete list of Plustek offices worldwide.

As a registered customer, you will receive customer support, new product information and software upgrades.

Thank you for choosing us as your scanner supplier. We hope you will continue to turn to us for additional quality products as your computing needs and interests grow.

How to Use This Guide

This User's Guide provides instructions and illustrations on how to install and operate your scanner. This guide assumes the user is familiar with Microsoft Windows XP, 98/Me and 2000 Professional. If this is not the case, we suggest you learn more about Microsoft Windows by referring to your Microsoft Windows manual before using your scanner.

The Introduction section of this manual describes the box contents and minimum computer requirements to use this scanner. Before you start installing your Plustek OpticPro scanner, check the box contents to make sure all parts are included. If any items are damaged or missing, please contact the vendor where you purchased your scanner or Plustek's customer service directly at one of the locations listed at the back of this manual.

Chapter I. Installing the Plustek OpticPro Scanner describes how to install scanner's software and connect the scanner to your computer. **Note: The scanner connects to your computer through the Universal Serial Bus (USB). If your**

computer does not support USB technology, you will need to purchase a USB interface card to add USB capabilities to your computer, or buy and install USB connectors if your motherboard has USB capabilities. This guide assumes that your computer is USB-ready and has a free USB port.

Chapter II describes how to test, maintain and clean your scanner. It also describes how to use the scanner utility program which helps you troubleshoot and fix connection problems which may have occurred during the scanner installation.

Appendices A & B have technical support information that can help you solve simple problems. Before calling for help, please read through Appendix A: Troubleshooting.

Appendix C contains Plustek's limited warranty agreement and FCC statement concerning the product.

Conventions of This Guide

Bold — Important note or first use of an important term in a chapter.

ALL CAPS — Represents commands or contents on your computer screen.

A Note about Icons

This guide uses the following icons to point out information that deserves special attention.



Danger

Danger: A procedure that must be followed carefully to prevent injury, or accidents.



Caution

Caution: Information that, if not followed, may result in data loss or damage to the product.



Attention

Pay Special Attention: Instructions that are important to remember and may prevent mistakes.

System Requirements¹

- Windows/Intel Compatible Personal Computer
 - Pentium CPU or above
 - CD-ROM Drive
 - 64 MB RAM (128 MB Recommended)
 - 160 MB Free Hard Disk Space (260 MB Recommended)
 - USB Port
 - Microsoft™ Windows XP, 98/Me or 2000 Professional
- NOTE:** Windows NT 4.0 does not support Universal Serial Bus (USB) connectivity.
- Video card that supports 16-bit color or greater

Box Contents²




Figure 1: Box Contents

1. Scanner³
2. USB Cable
3. Quick Installation Guide
4. Power Adapter
5. Setup / Application CD-ROM includes the following software applications⁴:

1 Higher requirements might be needed when scanning or editing a large quantity of image data. The system requirements here are only a guide line, as in general the better the computer (motherboard, processor, hard disk, RAM, video graphic card), the better the results.

2 Save the box and packing materials in case you need to transport this scanner in the future.

3 The scanner illustration(s) may appear different than from the actual scanner itself.

- Scanner Setup software
 - ABBYY FineReader Sprint 4.0 (OCR software)
 - NewSoft Presto! PageManager (Document Management Software)
 - NewSoft Presto! ImageFolio (Image Editing Software)
 - NewSoft Presto! Mr. Photo (Photo Organizer)
 - Bridgewell Page abc (Scan-to-Web Software)
 - Action Manager 32
 - Adobe Acrobat Reader 4.0 (PDF Product Manuals Reading Program)
 - This User's Guide (Electronic version)
 - Software User's Guide (Electronic version)
 - Registration Form (Electronic version)
6. Slide and Negative holders⁵ (to be found on the underside of the scanner cover)

Product Information

Please fill in the following information for your own records. You will need it when you install the Setup/Application CD-ROM, as well as if you contact your dealer or Plustek service center in the future.

Serial Number:

(Located at the back of the scanner)

Date of Purchase: - -

⁴ The bundled software may change at any time without prior notice.

⁵ Available only to the scanners equipped with the transparency adapter.

Chapter I. Installing the Plustek OpticPro Scanner

Before installing your scanner, please verify that you have all of the proper components. A list of the package contents is provided in the *Box Contents* section on page 3 of this guide.



Figure 2: The Scanner⁶

Software Installation Requirements

Your scanner comes with the image-editing software (Presto! ImageFolio), OCR software (FineReader), document management software (Presto! PageManager), the scanner's driver, Scanner Utility and Action Manager 32 software. All of these software applications use approximately 160 megabytes of hard disk space after they are installed into your computer. To ensure ample room for the installation, as well as for scanning and saving images, a minimum of 260 megabytes of hard disk space is recommended.

The OpticPro USB scanner can only operate under the Microsoft Windows XP, 98/Me or 2000 Professional operating system.

Hardware Requirements

This scanner connects to your computer through the Universal Serial Bus (USB) which supports *hot Plug and Play*. To determine whether your computer is USB-capable, you must check the rear of your PC to locate a USB jack that looks the same as the one pictured below. Note that on some computers, the USB port at the rear of the computer may be occupied and additional ports may be found on the monitor or keyboard. If you are having trouble in locating the USB port on your computer, please refer to the hardware manual that came with your computer.

Upon examination, you should find one or two rectangular USB ports, which usually appear as shown below.

⁶ The scanner illustration(s) may appear different than from the actual scanner itself.




Figure 3: USB Ports


If you don't find such USB ports on your computer, then you need to purchase a certified USB interface card to add USB capabilities to your computer.


Installing and Setting up the Scanner

Please follow the step-by-step procedures described below to install the Plustek OpticPro USB scanner.

Step 1. Unlock Your Scanner First

This OpticPro scanner has a locking mechanism to hold the scanning head in place during transportation. The locking switch located on the underside of the scanner is pictured below:



Please ensure to slide the locking switch to the unlock position  before all hardware and software installation.



Attention

Please take the time to lock the scanner head in place by switching to the lock position before moving the scanner in the future. This will help ensure accurate and problem-free use of your scanner.



Step 2. Connecting the OpticPro Scanner to Your Computer

1. Please take a moment to study Figure 4.







Figure 4. Installing the Scanner

2. Plug the power adapter into the scanner's power receptor which can be identified by the symbol \oplus on its top (see Figure 4, Step 1).
3. Plug the other end of the power adapter into a standard AC power outlet (see Figure 4, Step 2).
4. Plug the square end (Type B connector) of the included USB cable to the USB port at the rear of the scanner (see Figure 4, Step 3). You can find a USB sign  beside the USB connector at the rear of the scanner.
5. Plug the rectangular end (Type A connector) of the USB cable to the USB port on the back of your computer (see Figure 4, Step 4).

Note: If there is another USB device connected to the computer, connect the scanner to an available USB port.



Type A Connector



Type B Connector

6. If you plan to connect your scanner to a USB hub⁷, make sure that the hub is connected to the USB port in your computer. Next, connect the scanner to the USB hub (see Figure 4, Step 5).

Note: If you do not have a USB port available, you might need to buy a USB port.




Attention

When possible, we recommend using the 4 foot (1.2 meters) USB cable provided with your scanner. If you wish to use a different USB cable, make sure that it is a fully rated twisted-pair USB cable and has a Type A connector at one end and a Type B plug on the other.

Step 3. Installing the Software

1. If the USB components on your computer are functioning correctly, they will automatically sense a new device connected to the USB port causing the following window to appear on your screen. **Note:** If your computer was off when you connected the scanner, the message below will be displayed when you turn the computer on and when Windows starts.



2. Please click on the NEXT button to continue. The following window will appear:

⁷ The USB hub is not included with the scanner.



3. Choose **SEARCH FOR THE BEST DRIVER FOR YOUR DEVICE [RECOMMENDED]** and click on the **NEXT** button again, opening the following window:



4. Next, please insert the Setup/Application CD-ROM, included with your scanner, into your CD-ROM drive. Click the **CD-ROM DRIVE** box once, causing a check to appear in it as shown above and then click on the **NEXT** button again. The following window will appear:



5. Click on the **NEXT** button to continue. Follow the on-screen instructions to install all software that your new USB scanner requires.
6. After the software is installed, close all open applications and click on the **FINISH** button to restart your computer now.

Please consult the following chapter for information on how to test, configure and use your new scanner.



Attention

If you encountered any problems during this procedure, please refer to the *Software Setup Troubleshooting* section below.

Software Setup Troubleshooting

Carefully review the steps outlined in this guide and the Quick Installation Guide that accompanied your scanner.

If you are still having problems, please check that:

- You have 160MB of free space on your hard disk drive.
- The scanner is plugged in and has power.
- You are using the USB cable supplied with the scanner.
- The square end of the USB cable is plugged into the rear of the scanner.
- The rectangular end of the USB cable is plugged into the back of your computer.

If you deviated from the installation procedures defined in this manual, please unplug the USB cable from the scanner and reinstall the software from the CD-ROM. To reinstall your scanner's software, click START, RUN, then type D:\Setup (where D represents the letter of your CD-ROM drive). Carefully follow all the installation instructions presented in the Setup Wizard. Reboot your computer when prompted, and plug the USB cable back into the scanner while your computer is still turned on.

If you still need support, you can contact Plustek at any office listed on the last page of this guide during normal business hours in that area.

Installing Additional Software


Your scanner is TWAIN compliant and functions with virtually all available TWAIN compatible software. If you purchase additional software to be used with your scanner, please make sure that it conforms to the TWAIN standard.

Installing the Transparency Adapter*

(*This section applies to only select models that have a transparency adapter)

The transparency adapter is located on the underside of the scanner lid and is a necessary tool when scanning slides or negatives. The transparency adapter already

comes installed in your scanner model. To activate it, simply plug it in as shown below.



Chapter II. Usage and Maintenance

Operating the Scanner

Your scanner accepts documents as small as business cards and as large as letter-sized documents. However, some software programs have limitations as to the information they can handle. The capacity of the computer's memory and free space on your hard drive can also limit the physical size of the document that you scan.

There are two different ways to operate the scanner:

1. From within an image-editing program that can acquire images from the scanner.
2. By using the Action Manager 32 program that is automatically installed as your scanner software.

Your scanner needs to be driven by some type of software program. Since all documents or images (whether text or pictures) that are acquired from the scanner are treated by your computer as images, most scanning will probably be done from an image-editing program where you can view, edit, save and output the scanned images. An image-editing program has been bundled with your scanner on the included Setup/Application CD-ROM. It will allow you to alter and correct any scanned images by using a variety of filters, tools and effects.

What about scanning text documents and editing them in a word processor? This is the role of Optical Character Recognition (OCR) software. OCR software converts the image files that are created from scanning text documents into text files that can be viewed, edited and saved by word processors. An OCR program has also been bundled on the included Setup/Application CD-ROM, and if you wish to use the scanner in this way you should install the OCR software that is included.

Action Manager 32 is a program that allows you to conveniently scan images and text without the need to work directly within any image-editing application (i.e. Presto! ImageFolio). Action Manager 32 also includes features to allow you to use your scanner as fax⁸ and copy machines⁹.

Please refer to the Action Manager 32 section of the *Software User's Guide* or the Action Manager 32 on-line Help (accessible by right-clicking on the Action Manager 32 window and choosing Help) for more information about these functions.

⁸ A fax/modem and fax software is required to send faxes.

⁹ A printer is required for the copy utility.

Testing the Scanner

The following test procedure checks to see if the scanner is properly functioning with your computer and the scanning software. Before testing your scanner, double check to make sure that all connections are securely fastened.

To properly test your scanner, please perform the following steps:

1. Open the scanner's document cover and place a picture onto the scanner glass headfirst and face-down.




Figure 5. Flatbed Scanner

2. Gently close the document cover.
3. Next, open the scanner's image-editing program. Click on the Windows START button and then PROGRAMS, PLUSTEK USB SCANNER, PRESTO! IMAGEFOLIO, and then PRESTO! IMAGEFOLIO LE.
4. When Presto! ImageFolio opens, click on FILE and then SELECT TWAIN SOURCE. In the window that opens, choose PLUSTEK USB SCANNER. Click on the SELECT button to close the window. This procedure allows Presto! ImageFolio LE to gain access to the scanner.
5. Within Presto! ImageFolio, click on FILE, ACQUIRE and then choose ACQUIRE.
6. The Plustek USB Scanner (TWAIN) window will open.
7. CLOSE the Guided Scan window and click the SCAN button.
8. If an image appears on your screen, your scanner is working properly.

To learn how to manipulate the image, please read the *Chapter II. The Scanner Software of the Software User's Guide*.



Attention

If the test failed in any way, please refer to *The Scanner Utility Program* section of this manual and follow the instructions therein.

The Scanner Utility Program

The Scanner Utility Program can help you get your new scanner up and running. In addition, it contains a number of other features to help you tailor and control the scanner.

Most significantly, the Scanner Utility Program checks to make sure that the scanner software is properly installed and the scanner and computer are communicating with each other.

Two other features of the Scanner Utility program are **the scanning lamp controls** and **the scanning position alignment utility**. The Scanner Utility allows you to turn the scanning lamp on and off, and define an idle time for the scanning lamp to automatically turn itself off. Also, it allows you to define the exact position on the scanning glass where scanning will begin. The scanner lock was designed to hold the scanning lamp in place during shipping, but some refinement of the initial scanning position may still be necessary.




Figure 6. Scanner Utility



Attention

The Scanner Utility program does NOT affect the quality of scanned images. It is only used to establish a connection with the scanner. Settings that affect the scanned image (i.e., color, size, readability, clarity, etc.) can be found in the scanner software programs and especially the TWAIN interface.

Connection Status

The first step to take when troubleshooting connection problems with your scanner is to check all physical connections. Make sure your scanner is plugged in and the USB cable is fit snugly into the rear of your scanner and computer.

Secondly, determine the status of your USB hardware and software configuration. To do this, please run the Scanner Utility program as described below:

1. Click on the START button, then choose PROGRAMS, PLUSTEK USB SCANNER and then SCANNER UTILITY.
2. Once the Scanner Utility window is open, locate and click on the USB button shown below:




This will check the status of your USB hardware and software configuration.

3. If there is a problem with the installation, the following message will appear:



If you receive the above message, please refer to the Scanning Problems section of Appendix A: Troubleshooting on page 20.



4. If the connection is OK, the following window will be displayed:



Aligning the Scanner

In most cases, the scanner doesn't need to be aligned but there are instances when the alignment might be required. You need to align the scanner only if parts of the scanned document are missing from any of its edges. For example, the heading of a document might be missing from the top edge after the document has been scanned.


To align the scanner, follow the steps below:

1. Place a photograph on the top right side of the scanner glass (near the back of the scanner). Please note that only part of the photograph will be scanned.
2. Select NORMAL from the ALIGNMENT SOURCE drop down menu.
3. Click on the SCAN button . Part of the photograph will be displayed in the ALIGNMENT window.
4. Click on the ALIGN POSITION buttons until the top left corner of the scanned photograph aligns with the top left corner of the preview window.
5. Click on the check mark button  when the alignment has been completed.

Lamp Control

The scanner's lamp may be turned ON and OFF manually in the Scanner Utility program. While there, you can also set a timer to turn the lamp off after the scanner has been idle for a designated amount of time.

To do this, click on the Windows START button and choose PROGRAMS, PLUSTEK USB SCANNER, SCANNER UTILITY. In the window that opens, find the Lamp Control section shown below:



Click on the On/Off switch at the far right of the section to immediately turn the scanning lamp on or off.

You may also set the default time for the lamp to automatically turn off after a scan by clicking the up or down arrows next to the area that reads “minutes to turn off lamp.”

Maintenance

To keep your scanner working smoothly, take a moment to review the following maintenance tips.



Caution

- Avoid using the scanner in a dusty environment. When it is not in use, keep the scanner covered. Dust particles and other foreign objects may damage the unit.
- Do not attempt to disassemble the scanner. There is danger of an electrical shock and opening your scanner will void your warranty.
- Do not subject the scanner to excessive vibration. It may damage the internal components.

- Be sure not to bump or knock the scanner glass as it is fragile and could break.
- Clean the scanner glass by lightly spraying a non-abrasive glass cleaner onto a soft lint-free cloth. Then, wipe the glass thoroughly with the cloth. **DO NOT SPRAY CLEANER DIRECTLY ONTO THE SCANNER GLASS.** Excess liquid residue may fog or damage the scanner.
- Your scanner operates best in temperatures between 10° C to 40° C (50° F to 104° F).

Removing the Document Cover

The document cover has been designed for easy removal so that larger items, such as bound books, can be placed on the scanner glass. To remove the cover, open it all the way. Place your other hand firmly at the back of the scanner and lift the document cover, separating it from the back of the scanner. To replace the cover, simply slide it back into place.

Using the Transparency Adapter*

(*This section applies only to select models that include a transparency adapter)

When scanning transparencies or photo negatives, it is necessary to use the transparency adapter included with your scanner. The adapter changes the light source for scanning from inside the scanner to the lid. In order to do this, you must plug in the transparency. After this is done, transparencies can be scanned much like normal images. **Be sure to change the SOURCE setting in the TWAIN window to 35mm Negative (See the *Software User's Guide* for information about how to use TWAIN)!**

The Frame Holders

When scanning photo negatives or slides, you must use a frame holder¹⁰. The illustrations below instruct you on the precise usage of these important tools.




Figure 7. Frame Holders

There are two types of frame holders (see Figure 7). The one with the large, single opening is for slides. The holder with the two smaller openings is for photo negatives. The frame holders guarantee the correct position of the slide or filmstrip while being scanned. To prevent misplacing this important tool and ensure that it is always available, be sure to replace it in the specially designed compartment under the lid.

¹⁰ The frame holders are located in the underside of the scanner's document cover.

Negative Film Scan




Figure 8. Negative Film Scan

1. Insert the negative film stripe into the appropriate holder (see Figure 8, Step ❶). There will be a small rectangular opening that is not covered by the film. **Do not cover this opening.** The opening is very important for calibration.
2. Place the frame holder onto the scanner glass. There are two notches in the frame of the scanner surrounding the scanner glass (see Figure 8, step ❷). The two tabs on the frame holder should be fit into the notches. When this is done, the film is perfectly positioned for scanning.

Slide Scan

1. Place the appropriate frame holder onto the scanner glass. There are two notches in the frame of the scanner surrounding the scanner glass (see Figure 9, Step ❶). The two tabs on the frame holder should be fit into the notches.
2. Insert the slide into the holder (see Figure 9, Step ❷). When this is done, the slide is perfectly positioned for scanning.




Figure 9. Negative Film Scan



Attention

Important Notes about Scanning Film

- Make sure the film is properly loaded into the frame holder and the frame holder is correctly positioned on the scanner glass (see above).
- Make sure you adjust the SOURCE in the TWAIN window to the appropriate **35mm Negative** or **35mm Slide** setting (see the TWAIN section of the *Software User's Guide* for more detailed information about scanner settings)
- Since photo negatives and slides are almost always enlarged, make sure you use a higher scanning resolution – for example, 600 dpi (see the TWAIN section of the *Software User's Guide*).
- Remember to replace the frame holders in the document cover when you are finished using them.

Appendix A: Troubleshooting

Scanning Problems

Most problems are easily solved, and some of the most common questions and their recommended solutions are listed below. If your computer cannot receive images from the scanner, please refer to the *Scanner Utility* section of this manual before you proceed.

Symptom: After following the installation instructions, my computer cannot find the scanner.

Cause 1: Some aspect of your computer system does not support USB.

Solution 1: Download and execute the file USBREADY.EXE at <http://www.usb.org/faq.html> to determine the level of your computer's USB support.

Cause 2: USB is not enabled in your BIOS settings.

Solution 2: Enable the USB controller in your BIOS settings. This is typically done by pressing a key¹¹ (usually , <F1> or <F10>) during startup. In the BIOS Settings screen that appears, find the option for USB and enable it. Exit and Save the changes you made. Your computer is rebooted automatically. Please consult your computer vendor before attempting to do this change.

Cause 3: The USB controller was improperly installed on your computer.

Solution 3: To reinstall the USB controller, click on the Start button, choose Settings and select Control Panel. In the window that opens, double-click on the Add New Hardware icon. Carefully follow the instructions that appear on your screen.

Symptom: The scanned image looks grainy on the screen.

Cause: Your video mode is not set to show more than 256 colors.

Solution: We recommend that you set your video mode to 16 bits per pixel (65536 colors) or higher. Please consult your video card, computer or Windows documentation to change the video mode.

Symptom: The scanner scans very slow.

Cause 1: You are running other applications in the background.

¹¹ Please consult your computer manual on how to modify your BIOS/CMOS settings.

- Solution1: Close all the other applications that are running in the background.
- Cause 2: You are scanning at a high resolution (DPI).
- Solution 2: Reduce the resolution. See Chapter 2 of the *Software User's Guide* for information about recommended resolution settings.
- Symptom: The scanned document comes out as strange characters on the screen after the OCR process is completed.**
- Cause 1: Text page was scanned upside down.
- Solution 1: Reverse the page and scan again.
- Cause 2: The OCR software is limited to certain types of documents, fonts and formats. You might be trying to scan a form, spread sheet, a hand written letter or a document with color text or color page.
- Solution 2: Scan a clean document that contains, preferably, one column and has black text on a white page.
- Symptom: The scanner is not in the list of supported scanners in other commercial software.**
- Solution: Select TWAIN as the scanner.
- Symptom: Unable to scan from other software other than the one that came with the scanner.**
- Solution: Enter the Scanner Setup within the program, Select TWAIN and you will see your scanner listed (e.g., Plustek USB Scanner).
- Symptom: Unable to save to a floppy diskette.**
- Cause 1: The floppy disk might be write protected.
- Solution 1: Move the write protection tab, located in the back of the diskette, to the closed position.
- Cause 2: Your disk might not be formatted.
- Solution 2: Format the diskette.
- Cause 3: There is not enough space available in the disk to save the document.
- Solution 3: Delete any files that you do not need from the floppy disk.
- Cause 4: You might be scanning your document at a high resolution. Documents scanned using higher resolution modes will take a considerable amount of disk space.
- Solution 4: Reduce the resolution. See Chapter 2 of the *Software User's Guide* for information about recommended resolution settings.

- Symptom:** The image looks good in the software that came with the scanner but it does not look good when I export the image to another program.
- Cause:** Different imaging programs use different Monitor Gamma settings.
- Solution:** Change the Monitor Gamma settings in either of the programs so that they match. Please consult the help files for each program to find out how to adjust the Monitor Gamma.
-
- Symptom:** The image looks good in the screen but is very dark when printed.
- Cause1:** The Monitor Gamma Settings or the scanner brightness settings are not set properly.
- Solution 1:** 1) Change the Monitor Gamma to a value between 1.0 and 1.5. Please consult your help file for information on how to adjust the Monitor Gamma.
2) Adjust the brightness control in the TWAIN window before scanning.
- Cause2:** The printer brightness setting is not set properly.
- Solution 2:** Adjust the brightness in the printer. Some printers allow you to change the brightness settings. Please consult your printer documentation.
-
- Symptom:** The scanned image takes too long to be sent with an email message.
- Cause1:** The image was scanned at a high resolution or is physically large.
- Solution1:** Scan at a lower resolution (DPI)
- Cause 2:** The Internet might be congested.
- Solution 2:** Try sending the message at a later time.
-
- Symptom:** The image that I sent through email looks good in my computer but it looks dark in the recipient computer.
- Solution:** The Monitor gamma settings should be approximately the same in your and the recipient computer.
-
- Symptom:** There is a grinding or rattling noise at the beginning of each scan.
- Cause:** The scanner engages the gears and it initializes itself before scanning.
- Solution:** This noise is normal to the operation of the scanner.
-
- Symptom:** A. -Disk is full- error is displayed when I click on the scan button.
- Cause:** Your computer is running low in resources. Your computer hard disk drive does not have enough space to process the image. This may be because you are scanning at too high of a resolution.
- Solution:** Obtain a larger hard disk or rescan at a lower resolution.

Symptom: A -Disk I/O error- message is displayed.

Cause 1: This error is caused if the hard disk drive does not have enough space available to process the image.

Solution 1: Make some space available in the hard disk drive by deleting any programs or files that you do not need.

Cause 2: Your hard disk drive might be heavily fragmented or it might contain some bad sectors.

Solution 2: Run the Scan Disk utility that came with your Windows computer. Please consult your computer documentation or the Windows help files on how to run the Scan Disk Utility.

Symptom: The error “Scanner not Found” that is displayed.

Cause 1: The USB cables are not connected properly.

Solution 1: Make sure that the cables are connected tightly and to the proper port.

Cause 2: The USB cable might be too long.

Solution 2: Please use the USB cable that comes with your scanner.

Cause 3: The scanner’s power cord is not connected properly.

Solution 3: Make sure that the AC adapter is connected to an outlet. If the scanner is connected to a Surge Protector, make sure that the Surge Protector is turned on.

Common -How-to- Questions

Symptom: How do I save the scanned image in JPG format?

Solution: In the Image-editor, click on FILE
Click on SAVE AS.
Select the folder where you want to save your image.
Select JPEG or JPG under Save as type:
Type the name of the file name for your image.

Symptom: How do I cut an image and paste in another program?

Solution: 1) Select the area that you want to cut.
2) Click on EDIT.
3) Click on CUT.
4) Start the program and open the document where you want to paste your image.
5) Click on EDIT.
6) Click on PASTE.

Please consult your program documentation on how to Cut and Paste if you have any more questions.

Symptom: How do I place a scanned image into my Word Processor?

Solution:

- 1) Find out what formats are supported by your Word Processor.
- 2) Write the name and the location of the file before you save it.
- 3) Save in a format supported by your Word Processor.
- 4) Depending on your Word Processor, select INSERT or IMPORT from your menu, then select IMAGE or PICTURE.

Consult your Word Processor documentation for more information on how to import images.

Symptom: How do I put my scanned text document in my Word Processor?

Solution:


- 1) Find out what formats are supported by your Word Processor.
- 2) Save in a format supported by your Word Processor.
- 3) Open the file that you saved from your Word Processor.

Symptom: How do I send a scanned image using my email program?

Solution:


Save your scanned image in a format that is supported by your email program (JPG, GIF or PNG are recommended). Once your picture is saved, consult the documentation of your email program on how to attach a file to a message.

Appendix B: Specifications¹²

Plustek OpticPro U24	
	
Physical dimensions	16.65" x 10.24" x 4.25" (423 x 260 x 108 mm)
Weight	5.5 Lbs (2.5 Kgs)
Operating Temperature	10° C to 40° C (50° F to 104° F)
Max. Scan Area	8.5" x 11.7" (216 mm x 297 mm)
Scan Method	Single Pass
Scan Modes	48-Bit Color (Software Enhanced) ¹³ 42-Bit Color Input/Output 14-Bit Grayscale 1-Bit Line-Art (Black & White)
Resolution	Optical 1200 x 2400 dots per inch (24000 dpi software interpolated)
Scanning Materials	Reflective color or black-and-white originals.
Protocols	TWAIN Compliant
Connection	USB Port
Lamp Type	Cold Cathode Lamp
Power Adapter	Power Output DC 24V, 550mA
Power Consumption	Operation – 13.2 watts maximum Idle – 6 watts
EMI	FCC Class B

¹² Hardware specifications may change at any time without prior notice.

¹³ 48-bit color can only be used with professional imaging software such as Adobe Photoshop 5.0 that supports more than 24-bit color images.

Plustek OpticPro UT24	
	
Physical dimensions	16.65" x 10.24" x 4.25" (423 x 260 x 108 mm)
Weight	5.72 Lbs (2.6 Kgs)
Operating Temperature	10° C to 40° C (50° F to 104° F)
Max. Scan Area	Reflectives: 8.5" x 11.7" (216 mm x 297 mm) Transparency: Slides, 35 mm film, negatives (36 x 24 mm)
Scan Method	Single Pass
Scan Modes	48-Bit Color (Software Enhanced) ¹⁴ 42-Bit Color Input/Output 14-Bit Grayscale 1-Bit Line-Art (Black & White)
Resolution	Optical 1200 x 2400 dots per inch (24000 dpi software interpolated)
Scanning Materials	Reflective color or black-and-white originals, slides, films.
Protocols	TWAIN Compliant
Connection	USB Port
Lamp Type	Cold Cathode Lamp
Power Adapter	Power Output DC 24V, 550mA
Power Consumption	Operation – 13.2 watts maximum Idle – 6 watts
EMI	FCC Class B
Others	Built in with a transparency adapter to scan slides, films and transparency.

14 48-bit color can only be used with professional imaging software such as Adobe Photoshop 5.0 that supports more than 24-bit color images.

Appendix C: Customer Service and Warranty

If you encounter problems with your scanner, please review the installation instructions and troubleshooting suggestions contained in this guide.

For further assistance call our customer support phone number listed on the last page of this guide. One of our representatives will be happy to assist you from Monday through Friday in office working hours as shown below:

Europe	9:00 a.m. – 5:30 p.m.
Other Countries or Areas	9:00 a.m. – 6:00 p.m. Taiwan Time

To avoid delays, please have the following information available before calling:

- **Scanner name and model number**
- **Scanner serial number (located at rear of scanner near port connectors)**
- **A detailed description of the problem**
- **Your computer manufacturer and its model number**
- **The speed of your CPU (Pentium 133, etc.)**
- **Your current operating system and BIOS (optional)**
- **Name of software package(s), version or release number and manufacturer of the software**
- **Other USB devices installed**

Statement of Limited Warranty

This Statement of Limited Warranty applies only to the options you originally purchase for your use, and not for resale, from an authorized reseller.

The manufacturer warranty includes all parts and labor, and is not valid without the receipt of original purchase. To obtain warranty service, you may contact the authorized dealer or distributor, or visit our website to check out the available service information, or send a request via E-mail for further help.

If you transfer this product to another user, warranty service is available to that user for the remainder of the warranty period. You should give your proof of purchase and this statement to that user.

We warrant that this machine will be in good working order and will conform to its functional descriptions in the documentation provided. Upon provision of proof of purchase, replacement parts assume the remaining warranty of the parts they replace.

Before presenting this product for warranty service, you must remove all programmes, data and removable storage media. Products returned without guides and software will be replaced without guides and software.

This Limited Warranty service does not provide for carry-in exchange when the problem results from accident, disaster, vandalism, misuse, abuse, unsuitable environment, programme modification, another machine or non-vendor modification for this product.

If this product is an optional feature, this Limited Warranty applies only when the feature is used in a machine for which it was designed.

If you have any questions about your Limited Warranty, contact the approved retailer from whom you bought the product or the manufacturer.

THIS LIMITED WARRANTY REPLACES ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. HOWEVER, SOME LAWS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. IF THESE LAWS APPLY, THEN ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO OTHER WARRANTIES APPLY AFTER THAT PERIOD.

Some jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply.

Under no circumstances are we liable for any of the following:

1. Third party claims against you for losses or damages.
2. Loss of, or damage to, your records or data; or
3. Economic consequential damages (including lost profits or savings) or incidental damages, even if we are informed of their possibility.

Some jurisdictions do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This Limited Warranty gives you specific legal rights, and you may also have other rights that vary from jurisdiction to jurisdiction.

To obtain the warranty service, you may:

- contact the authorized dealer or distributor.
- visit our website to check out the up-to-date service.
- send a request via E-mail for further help.

FCC Radio Frequency Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular television reception (which can be determined by turning the equipment off and on), the user is encouraged to try to correct the interference by one or more of the following measures:

- √ Reorient or relocate the receiving antenna.
- √ Increase the separation between the equipment and receiver.
- √ Connect the equipment to an outlet on a circuit different from that which the receiver is connected.
- √ Shielded interconnect cables and shielded power cord which are supplied with this equipment must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device.
- √ Consult the dealer or an experienced radio/TV technician for help if the conditions persist.
- √ Changes or modifications not expressly approved by the manufacturer or authorized service center could void the user's authority to operate this equipment

Contacting Plustek

EUROPE

Plustek Technology GmbH
Gutenbergring 38, 22848 Norderstedt, Germany

Pan-Europe

Tel.: +49 (0) 40 523 031 30
Fax: +49 (0) 40 523 035 00
E-mail: support@plustek.de
Website: www.plustek.de

Great Britain & Ireland

Tel.: +44 (0) 870 90 16 834 (support engineers)
+44 (0) 870 90 16 835 (24 hr. Automated Support)
Calls charged at national rates
Fax: +44 (0) 870 90 16 832
E-mail: support@digitequk.com

Other Countries or Areas

Plustek Inc.
8th Fl, No. 48, Sec. 3, Nan Kang Road, Taipei, Taiwan
Tel: +886-2-2651 5311 Ext. 3173 or 3174
Fax: +886-2-2651 5310
E-mail: support@plustek.com.tw
Website: www.plustek.com